





To Operate Camera:  
Touch Camera in upper right



To Share Document Camera or PC:  
Touch Share.



To Change Remote Site Layout:  
Touch Layout icon




# Touch Panel Features

## Recording


To start recording, touch Record and touch Start recording.

An automated voice will indicate that the conference is recording.




To stop recording, touch Record and touch Stop recording.

An automated voice will indicate that the recording has stopped.



& 7 5 BE \$5 ? @ = ! 9 ! \$ 5 ? @ = E \$ ! \$ ° E

' : E @ - 9 E ! \$ E 9 f E O ' E ? . @ + 4 E + ) 8 . ⇒ E 5 : 9 E ) 9 - E ? . @ + 4 E 4 . E 4 . + 6 \* : C E  
9 . C E ? E & 7 5 B E



HVCC Test Space

HVCC Test Space

Selfview

' : E 4 ) 9 3 E % 8 : ? E & E ' ) D @ 7 E

\$ 4 D 5 ) 7 E @ ? ? 9 7 E

# H B C 3 D ; @ + 4 E ' ) D @ 7 E 5 : 9 E

EXT 01 0 17

